

DISPENSER PRODUCT CHANGEOVER

CHANGING THE CONTAINER

1. Always wear Personal Protective Equipment (PPE) such as safety glasses and suitable gloves before changing chemical containers. (Refer to Safety Data Sheets in the event of any spillages)
2. Ensure new container is close by to the empty container before unscrewing new container lid.
3. Once new container lid has been removed, carefully remove feed line from empty container and move into new container. (Never manually decant left over chemical from one container to another)
4. Ensure feed line is reaching the bottom of the new container.
5. Tighten new container lid.

PRODUCT IS READY FOR USE!